

3G Data Card Connectors

Manufacturers	Model	Connector	Device Type
Huawei			
Huawei	E160	CRC9	USB Modem
Huawei	E160E	CRC9	USB Modem
Huawei	E160G	CRC9	USB Modem
Huawei	E156G	CRC9	USB Modem
Huawei	E159	CRC9	USB Modem
Huawei	E153	CRC9	USB Modem
Huawei	E122	CRC9	USB Modem
Huawei	E1553	CRC9	USB Modem
Huawei	E161	CRC9	USB Modem
Huawei	E1612	CRC9	USB Modem
Huawei	E166	CRC9	USB Modem
Huawei	E169	CRC9	USB Modem
Huawei	E173	CRC9	USB Modem
Huawei	E176	CRC9	USB Modem
Huawei	E176G	CRC9	USB Modem
Huawei	E1762	CRC9	USB Modem
Huawei	E176G	CRC9	USB Modem
Huawei	E182	CRC9	USB Modem
Huawei	E182E	CRC9	USB Modem
Huawei	E1820	CRC9	USB Modem
Huawei	E1823	CRC9	USB Modem
Huawei	E196E	CRC9	USB Modem
Huawei	E196G	CRC9	USB Modem
Huawei	E367	CRC9	USB Modem
Huawei	E353	CRC9	USB Modem
Huawei	E398	TS-9	USB Modem
Huawei	K4505	CRC9	USB Modem
Huawei	K4511	CRC9	USB Modem
Huawei	K3771	CRC9	USB Modem
Huawei	UMG181	CRC9	USB Modem
Huawei	UMG1691	CRC9	USB Modem
Huawei	E600	CRC9	PCMCIA Card
Huawei	E612	CRC9	PCMCIA Card
Huawei	E618	CRC9	PCMCIA Card
Huawei	E620	CRC9	PCMCIA Card
Huawei	E621	CRC9	PCMCIA Card
Huawei	E630	CRC9	PCMCIA Card
Huawei	E660	CRC9	PCMCIA Card
Huawei	E660A	CRC9	PCMCIA Card
Huawei	E881E	CRC9	Express Card
Huawei	E800	SSMB	Express Card

3G Data Card Connectors

Manufacturers	Model	Connector	Device Type
ZTE	MF622	MS147	USB Modem
ZTE	MF636+	M852	USB Modem

Sony Ericsson

Sony Ericsson	Express Cards EC400	SSMB	Express Cards
Sony Ericsson	Express Cards EC400G	SSMB	Express Cards
Sony Ericsson	PCMCIA Cards PC300	SSMB	PCMCIA Cards

Ericsson

Ericsson	W20	SMA	Router
Ericsson	W21	SMA	Router
Ericsson	W25	SMA	Router
Ericsson	W30	MCX	Router
Ericsson	W35	MCX	Router

3G Data Card Connectors

Manufacturers	Model	Connector	Device Type
Sierra Wireless	Express Cards AC597E	SSMB	Express Card
Sierra Wireless	Express Cards AC880E	SSMB	Express Card
Sierra Wireless	Express Cards AC881E	SSMB	Express Card

Novatel Wireless

Novatel Wireless	U760	TS-9	USB Modem
Novatel Wireless	MCD3000	MS-147	USB Modem
Novatel Wireless	USB720	MS-147	USB Modem
Novatel Wireless	U720	MS-147	USB Modem
Novatel Wireless	U727	TS9	USB Modem
Novatel Wireless	USB760	TS9	USB Modem
Novatel Wireless	U727	TS-9	USB Modem
Novatel Wireless	USB MC727	TS-9	USB Modem
Novatel Wireless	USB MC760	TS-9	USB Modem
Novatel Wireless	MC930D	Universal	USB Modem
Novatel Wireless	MC950D	Universal	USB Modem
Novatel Wireless	C770	TS-9	PCMCIA Card
Novatel Wireless	C777	TS-9	PCMCIA Card

Option Wireless

Option Wireless	3G QUAD	MC-card	PCMCIA Card
Option Wireless	Express 7.2	MC-card	PCMCIA Card
Option Wireless	7.2 HSDPA	MC-card	PCMCIA Card
Option Wireless	EDGE	MC-card	PCMCIA Card
Option Wireless	GT EDGE	MC-card	PCMCIA Card
Option Wireless	Globe trotter FUSION	MC-card	PCMCIA Card
Option Wireless	GT MAX	MC-card	PCMCIA Card
Option Wireless	GlobeTrotter GT Max 7.2	MC-card	PCMCIA Card
Option Wireless	HSDPA	MC-card	PCMCIA Card
Option Wireless	MAX HSDPA	MC-card	PCMCIA Card
Option Wireless	GlobeSurber	MC-card	PCMCIA Card
Option Wireless	Express HSUPA	MC-card	Express Card
Option Wireless	Express HSDPA	MC-card	Express Card
Option Wireless	Globesurfer III	MC-card	Router
Option Wireless	GlobeSurfer II	MC-card	Router

ZTE

ZTE	MF633	TS-9	USB Modem
ZTE	MF633BP+	TS-9	USB Modem
ZTE	MF626i	TS-9	USB Modem
ZTE	MF645	TS-9	USB Modem
ZTE	MF668	TS-9	USB Modem
ZTE	MF668+	TS-9	USB Modem
ZTE	MF60	TS-9	USB Modem

3G Data Card Connectors

Manufacturers	Model	Connector	Device Type
Huawei	E870	SSMB	Express Card
Huawei	E880	SSMB	Express Card
Huawei	B932	SMA	Router
Huawei	B933	SMA	Router
Huawei	B970	SMA	Router
Huawei	E960	SMA	Router
Huawei	E968	SMA	Router
Huawei	E583C	CRC9	Router
Huawei	B220	SMA	Router

Sierra Wireless

Sierra Wireless	USB Sticks AC880U	SSMB	USB Modem
Sierra Wireless	USB Sticks AC881	SSMB	USB Modem
Sierra Wireless	USB Sticks AC881U	SSMB	USB Modem
Sierra Wireless	USB Sticks APEX880	SSMB	USB Modem
Sierra Wireless	USB Sticks Compass 885	TS-9	USB Modem
Sierra Wireless	USB Sticks Compass 888	TS-9	USB Modem
Sierra Wireless	USB Sticks Compass 889	TS-9	USB Modem
Sierra Wireless	USB Sticks USB597	TS-9	USB Modem
Sierra Wireless	USB Sticks USB598	TS-9	USB Modem
Sierra Wireless	USB Sticks AC250U	TS-9	USB Modem
Sierra Wireless	AirCard USB301	TS-9	USB Modem
Sierra Wireless	AirCard USB302	TS-9	USB Modem
Sierra Wireless	AirCard USB305	TS-9	USB Modem
Sierra Wireless	AirCard USB306	TS-9	USB Modem
Sierra Wireless	AirCard USB307	TS-9	USB Modem
Sierra Wireless	USB Sticks 308	TS-9	USB Modem
Sierra Wireless	USB Sticks 309	TS-9	USB Modem
Sierra Wireless	AirCard 310U	TS-9	USB Modem
Sierra Wireless	AirCard 312U	TS-9	USB Modem
Sierra Wireless	PCMCIA Cards AC555D	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA Cards AC503	TS9	PCMCIA Card
Sierra Wireless	PCMCIA Cards AC504	TS9	PCMCIA Card
Sierra Wireless	PCMCIA Cards AC580	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA Cards AC775	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA Cards AC850	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA Cards AC860	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA Cards AC875	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA Cards AC880	SSMB	PCMCIA Card
Sierra Wireless	Express Cards AC402	TS-9	Express Card
Sierra Wireless	Express Cards AC501	TS-9	Express Card
Sierra Wireless	Express Cards AC502	TS-9	Express Card
Sierra Wireless	Express Cards AC503	TS-9	Express Card